




- 1 Art. Nr. 10581VRC
Kaffebecher
- 2 Art. Nr. 10851VRC
Kaffebecher
- 3 Art. Nr. 10845VRC
Teekanne




- 1 Art. Nr. 11078-1VRC
Zuckerdose 11,5 cm
- 2 Art. Nr. 11379VRC
Frühstückstasse mit Untere
- 3 Art. Nr. 11642-1VRC
Moccatasse mit Untere
- 4 Art. Nr. 10953VRC
Kaffeetasse mit Untere



- 1 Art. Nr. 11078-2VRC
Gießer 9,5 cm
- 2 Art. Nr. 10474-1VRC
Serviettenhalter 14 cm
- 3 Art. Nr. 21094VRC
Schale 3-Fuß 13 cm




- 1 Art. Nr. 10228VRC
Schale 18 cm durchbrochen
- 2 Art. Nr. 10229VRC
Schale 22 cm durchbrochen




- 1 Art. Nr. 10227VRC
Schale 12 cm durchbrochen
- 2 Art. Nr. 10896-2VRC
Teller 20 cm



- 1 Art. Nr. 9879VRC
Ascher 15 cm
- 2 Art. Nr. 10923-2VRC
Dose 15 cm
- 3 Art. Nr. 10892VRC
Tasche 11 cm



- 1 Art. Nr. 10690-1VRC
Uhr 20 cm
- 2 Art. Nr. 10839-5VRC
Vase
- 3 Art. Nr. 10482VRC
Platte 25 cm



- 1 Art. Nr. 10810VRC
Stollenplatte 38 cm
- 2 Art. Nr. 10561-1VRC
Vase durchbrochen 12 cm
- 3 Art. Nr. 11299VRC
Vase 11 cm



- 1 Art. Nr. 10839VRC
Vase 17,5 cm
- 2 Art. Nr. 3010VRC
Vase 21 cm
- 3 Art. Nr. 9845VRC
Vase 26 cm
- 4 Art. Nr. 9845-2VRC
Vase 13 cm